

RUST INDUSTRIES

SPECIFICATION

Standard system comprises: -

1 Receiver unit
1 Transmitter (Radio key)
Pre-Coded

RECEIVER SWITCHING UNIT

SUPPLY	10 – 24 V AC/DC
RADIO FREQUENCY	433.92 MHz AM
OPERATING TEMP	-20°C to + 70°C
RELAY	8A @ 240V AC
CONNECTION	SCREW TERMINALS
DIMENSIONS	H 75mm, W 50mm, D 27mm (Excluding gland)

TRANSMITTER

RF OUTPUT	433.92 MHz AM
SUPPLY	12V Battery
CODE	24 BIT
LICENCE	WT MPT 1340 LICENCE EXEMPT
DIMENSIONS	H 57mm, W 36mm, D 15mm

As with all radio frequency based equipment, it is possible that external interference and environmental conditions can significantly affect the performance, therefore it is essential that this product is not used where failure of operation could be considered dangerous or result in damage or loss to property.

In the interest of continued development, Rust Industries reserves the right to alter the specification of this product without prior notice.

For further information contact

Rust Industries
Lyon Road, Atlantic Street
Broadheath, Altrincham
Cheshire
WA14 5DG

Tel: 0161-929-7550 Fax 0161-929-7551

REMOTE SWITCHING UNIT RCU-02

The RCU-02 is a radio remote controlled switching unit that will allow the remote operation of any appropriate electrical appliance that is required. The unit is constructed to commercial standards, giving the convenience of remote operation and in most cases the reduction in installation costs will exceed the cost of switching unit.

The output of the unit is in the form of a relay change over contact rated at 8 amps 240V AC. On the reception of a valid signal the output can be programmed to be momentary, toggled or timed using the internal dip switches.

The remote control is achieved by using an encoded UHF radio signal produced by a key fob transmitter with a super-hetrodyne receiver validating the transmitted code and activating the output accordingly.

The RCU-02 receiver requires a supply of 10 to 24V AC/DC and the output is via a pair of voltage free changeover relay contacts.

INSTALLATION

First remove the lid and carefully retain the 4 lid screws.

The DIP switches should be positioned in line with the table (overleaf), in order to establish the correct output control (Latched, momentary or timed).

The receiver unit must be securely mounted, using the mounting bracket provided, vertically with the active part of the aerial (last 155mm) being positioned away from any metal shielding and extended as far as practically possible. Avoid positioning in close proximity to electronic equipment as interference from such equipment in certain circumstances could reduce the operational range.

The unit is not designed to be weatherproof and should be located in a suitable dry environment

The wiring must be passed through the sealing gland, and connected appropriately (see diagram). Ensure that the supply to the unit is appropriately fused and if there is any doubt whatsoever regarding the electrical installation consult a competent qualified electrician. The cables must be clamped securely by tightening the sealing gland using a 15mm spanner ensuring that an adequate clamp is formed against the outer sleeving of the cables.

All connections to the unit must be made via the screw blocks provided. Ensure that there are no loose strands of wire present and that all connections are secure. If the load requires an earth, this **MUST** be provided.

Terminals 4 and 5 are electrically connected, therefore terminal 4 can be used to link the supply to the relay contacts if required.
Refer to 'Wiring diagram' for connection details.

Before applying power ensure that the installation is both complete and safe, and secure lid with the four screws provided.

After the power is applied allow approximately 5 seconds for the electronics to stabilise. Activation of the remote transmitter will activate the receiver output, provided that it is within range.

CODING RADIO KEYS INTO UNIT

Normally the unit is supplied with 1 dual button radio key coded into the unit.

In this situation, when the unit is first powered the unit will enter **AutoCoding** (see below), after a key has been added or ten seconds have elapsed the LED will illuminate green, indicating that power is applied to the unit and has been pre-programmed to respond to at least one radio key. If the LED is red this indicates that the unit has no radio keys programmed.

The unit is capable of responding to 9 radio keys of differing codes

Programming

1. Press and release the function button (see diagram), the LED will extinguish for a brief period, followed by a 10 second coding period. During this period the LED will flash green, the number of times the LED flashes correspond to the number of radio keys that are coded into the unit. (If the LED does not flash then no radio keys are programmed).
2. Press a button on the radio key that is required to be coded into the unit, the LED will flash yellow briefly to confirm that the unit has accepted the radio key.
3. The LED will illuminate green to show that normal operation has resumed, and the unit will respond to the newly coded key. If the unit does not respond to the key then this will probably due to the 10 seconds allowed for coding having elapsed before the key fob button has been pressed (in this case go back to step 1) or the unit already has the maximum 9 radio keys programmed.

Auto Coding

In some applications it is inconvenient to access the coding button. In this instant it is possible to add radio keys by following the procedure below:

1. Disconnect the power supply.
2. Re-connect the supply and immediately press the corresponding button on the radio key that you require to be added within range of the receiver. The unit will learn and store the code from the radio key and regard the code as valid.

NB. The unit will **not** 'learn' the radio key code if more than ten seconds have elapsed after applying power before the radio key button is pressed or if the unit has the maximum number of keys already stored. If the unit receives a code that is already programmed the unit will leave 'Auto-coding' and operate normally.

It not possible to delete keys without access to the 'coding button'

Deletion of radio keys

To delete the radio keys programmed into the unit, press the function button for 10 seconds, the LED will illuminate yellow to confirm that the radio keys have been erased. Release the function button, the LED will go red showing that receiver unit is blank and is NOT programmed to accept radio keys.

To re-enter radio keys see "PROGRAMMING" section above

Output Set-up

NOTE: As viewed from the front with the aerial at the top, the dipswitches are in 1 block of 4. These are numbered from **RIGHT to LEFT** with the **OFF** position **UPWARDS** and the **ON** position **DOWNWARDS**

DESIRED OUTPUT			SINGLE BUTTON CONTROL		SWITCH POSITION			
			ACTIVATION MODE		4	3	2	1
MOMENTARY			PROGRAMMED BUTTON		OFF	OFF	OFF	OFF
10 SECS	TIMED		PROGRAMMED BUTTON		OFF	OFF	OFF	ON
25 SECS	TIMED		PROGRAMMED BUTTON		OFF	OFF	ON	OFF
1 MIN	TIMED		PROGRAMMED BUTTON		OFF	OFF	ON	ON
5 MINS	TIMED		PROGRAMMED BUTTON		OFF	ON	OFF	OFF
20 MINS	TIMED		PROGRAMMED BUTTON		OFF	ON	OFF	ON
1 HOUR	TIMED		PROGRAMMED BUTTON		OFF	ON	ON	OFF
ALTERNATE			PROGRAMMED BUTTON		OFF	ON	ON	ON
DESIRED OUTPUT			DUAL BUTTON CONTROL.		SWITCH POSITION			
			ACTIVATION MODE		4	3	2	1
10 SECS	TIMED	BUTTON 1 SETS	BUTTON 2 OFF	ON	OFF	OFF	OFF	OFF
25 SECS	TIMED	BUTTON 1 SETS	BUTTON 2 OFF	ON	OFF	OFF	OFF	ON
1 MIN	TIMED	BUTTON 1 SETS	BUTTON 2 OFF	ON	OFF	ON	OFF	OFF
5 MINS	TIMED	BUTTON 1 SETS	BUTTON 2 OFF	ON	OFF	ON	ON	ON
20 MINS	TIMED	BUTTON 1 SETS	BUTTON 2 OFF	ON	ON	OFF	OFF	OFF
1 HOUR	TIMED	BUTTON 1 SETS	BUTTON 2 OFF	ON	ON	OFF	ON	ON
2 HOUR	TIMED	BUTTON 1 SETS	BUTTON 2 OFF	ON	ON	ON	OFF	OFF
INDEFINITE		BUTTON 1 SETS	BUTTON 2 OFF	ON	ON	ON	ON	ON

WIRING DIAGRAM

